

Ofcom Frequency license Booking Guide

NanoPro I Eagle I Helios Transmitter



Contact Us





Each transmitter will need one OFCOM frequency license.

For Heli Licences (helicopter) - email requirements to:pmse cpmse@ofcom.org.uk>

To book a frequency simply register with Ofcom with your own account on their website and then book your licence.


The process is very simple but if you get stuck, please call Ofcom directly, 020 7981 3803 They can walk you through the process to register and bookyour licence.

Step one:

Register for PMSE licences as a NEW USER at Ofcom website:

Follow this link:

https://pmse.ofcom.org.uk/PMSE/ecom/Private/CustomerWelcomePage.aspx








Step two:

Once registered with an account go to Book Frequencies in the left navigation pane. (9 down.)




Check the box and then select "New Basket."








Frequencies are booked for a period of time and specific area:




The frequencies need to be in the 2.0 - 2.2Ghz range [Unless the on-set technician has specified otherwise]








Choose one available frequency per transmitter/camera, and then add to basket:



When you're happy - check out and pay. Make sure to select the confirm button and then proceed:







Finally, proceed with payment and follow the instructions

